


WALL HANGERS ASSEMBLY INSTRUCTION

This page lists the contents included in the box. Please take time to identify the hardware as well as the individual components of the product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage. Please follow the assembly instructions closely. Improper assembly can cause personal or property damage.



WARNING: CHOCKING HAZARDS

Small parts present in unassembled state.
Adult assembly required.
Hang the item high up out of children's reach.



CLEANING AND CARE:

Clean surfaces with dry or damp soft cloth. Do not use abrasive cleaners.
Periodically tighten bolts as necessary.

SAFETY MOUNTING INSTRUCTIONS:

For added safety and stability, it is recommended installing wall mounting hardware. For safe mounting, it is essential to use wall anchors appropriate to your wall type (i.e. plaster, dry wall, concrete, ect.).

NOTE: If you are unsure about your wall type or what mounting method you should use, consult a qualified professional or your local hardware store.

HARDWARE

Plug X 02 Screwdriver X 01
(not included)



Screw X 02 Level tool X 01
(not included)



ASSEMBLY INSTRUCTIONS

1. Make the drilling points on the wall according to your product's size and insert the plugs.
2. Install the screws through the product hangers.

Maximum Weight Capacity: 15 Libra\Pound - 7 Kilogram.

ANJOY YOUR ART.

